Sonos Play

Overview

Powerful, portable, and ready for anything. Play delivers big stereo sound and all-day battery life wherever you go.

- **Big sound. Just the right size.** The dual tap tweeter and dual bass ducts in a purpose-designed enclosure deliver rich, room-filling sound. Small enough to take anywhere, big enough to impress.
- **Battery life to go where you are.** Use all day with up to 10 hours of playback, and recharge easily with the included charging base. Optimized power management extends every charge, and when it's time for a recharge, it only takes about 3 hours.
- **Ready for whatever your day holds.** Don't sweat accidents in the adventure. Play is rated IP67 for waterproof and dustproof protection, and the durable design packs handles, drops and bumps.
- **Stream music from anywhere.** Play connects to your Wi-Fi network, so you can stream music over the cloud from your favorite services. Connect directly with Bluetooth® to enjoy Sonos-quality playback. Pause to take a call, then hop right back to the music.
- **Sonos everywhere—even off the grid.** Take Sonos anywhere beyond your home. Create group up to 32 speakers, and control them all with the Sonos app. Add a Sonos Amp, Port, or Connect to your home system.
- **Power more than your music.** Go beyond the playback. Play doubles as a built-in alarm so you can keep your phone charged and your playing wherever the alarm goes.

Controls and lights

Volume control

- Volume up (press +)
- Volume down (press –)

Note: When music is playing, press and hold + or – to quickly change the volume.

Play/Pause

- Press once to play or pause audio.
- Press and hold to sign in with the audio that's playing or another source (all on supported).

Next

- Double-press (skip/pause to skip to the next track).

Note: You can't skip forward on a live stream. Volume is a radio station.

Previous

- Triple-press (skip/pause) – to go to the previous track.

Note: You can't skip backward on a live stream. Volume is a radio station.

Voice services on/off

Press the voice service button to turn voice control on or off. You can set up a voice service in the Sonos app.

- When the light is on, voice control is enabled.
- When the light is off, voice control is disabled.

Note: Make sure the external microphone switch on the back is turned on.

Status light

Displays the product's connection to Wi-Fi or Bluetooth, indicates when the battery is charged, and signals error. **Learn more**

Battery light

Indicates the battery status:

- Blinking: charging or battery low
- Solid: charge complete (Play has started charging). The light will stay on for 10 seconds then turn off, unless the battery is very low.

Note: Check battery level in the Sonos app.

Connector panel

1	**Strap**
2	**Bluetooth button**
3	**Universal microphone switch**
4	**Power button**
5	**USB-C port**
6	**Charging dock**

Attach for heavy-lifting and carrying (or you can take the Play wherever you go).

To reduce the strap, use a 3-mm hex key. The internal thread noted earth is 10.5.

Press to connect to a mobile device via Bluetooth. Play will connect to the last device it connected to.

Press again to disconnect the current device.

Press and hold to pair a new device.

Turn the microphone on or off. Press once to set a voice service to the Sonos app.

- When the switch is off (closer), the microphones are disabled or microphone-based features like auto Trueplay and voice control are unavailable.
- When the switch is on (up), microphone-based features like auto Trueplay are available. Sonos can't control or hear your voice unless you initiate night on by the product or also act.

Note: Make sure the external microphone switch on the back is turned on.

Press to power on. The status light turns on and you hear a tone.

Press to exit to sleep. The status light turns off and you hear a short tone.

Press and hold about 10 seconds to power off. The status light turns off and you hear a tone.

Note: The Sonos will automatically go into sleep mode after 20 minutes of inactivity.

- **Power.** Use a compliant USB PC power supply (5 V/0.5 A recommended) to charge Play via the USB-C port.
- **Ethernet.** Use the Sonos Cordia Adapter and an Ethernet cable to connect Play directly to your router. Play will switch to the wired network if your Wi-Fi is unavailable.
- **Line-in.** Use the Sonos Cordia Line-in Adapter or Cordia Adapter to connect your turntable, TV, or other audio source to Play.

Power tools. The Beyblade is a power tools or you can buy your power tools at a store.

Set Play on the charging base and it stays active for an hour so you can quickly top off the battery.

Charging

Charging base	Set Play on the charging base for easy recharging. The battery light will turn on and off. Charging is complete when the light turns off. Use only the charging cradle and the charging contacts (on the bottom). The charging base is for indoor use only. Do not use outdoors. **Note:** Check battery level in the Sonos app.
USB-C port	Play is designed to work with a 5 V/0.5 A compliant USB PC power supply (1.5 A recommended). Play can charge your phone or power other devices via USB-C connection.

Battery Saver

Battery Saver helps you get more out of Play's battery. When enabled, your Play will power off automatically after 5 minutes of idle playback. Press the **Play/Pause** button to wake Play.

Go to **Settings** > **Battery Saver** and tap to enable.

Note: Play won't appear in the Sonos app until it's powered back on.

Bluetooth pairing

1. Turn Bluetooth on in your device settings.
2. Press and hold the Bluetooth button at the top of the speaker until you hear a tone, then release. The status light blinks blue when the speaker is ready to pair.
3. Select Play in the list of available devices in your Bluetooth settings. Your mobile device will automatically connect and have you access the Bluetooth button.

Select a location

Play is designed to sound great in many locations. For optimal performance, here's a few guidelines:

- For best performance, leave at least 1.2" (3 cm) space around the back of Play when placing it next to a wall or shelf.
- In a tiny speaker. With a tough outer shell and IP67 rating, Play is built for withstand falls, bumps, moisture, dust, and the occasional accidental dunk. Play is not designed for submersion.
- Cordia and Trueplay™ in the Sonos app—Play can be used for playback outside of a Sonos setup but you can't add your device to a Sonos system.

Note: Sonos doesn't support or guarantee products with the features will be available as soon as Sonos and a third-party device support together in any region.

Microphone on/off

Play has microphones in Play that used for voice control and other features found in the **Sonos app**. Set with Trueplay™.

Play has seven tweeters so top-quality triggers voice control on and off the privacy unless affecting the microphones needed for each Trueplay and other microphone-based features.

The universal microphone switch on the back allows you to turn on or off all microphones in the speaker and voice services. When the microphone switch is turned off, the microphone is disabled. When disabled, Play will function like a non-networked speaker with an unavailable.

When the voice service light is on:

- The microphone switch on the back is locked.
- The universal microphone switch is on.

When the voice service light is off:

- You can use the microphone switch on the back.
- The universal microphone switch is on.
- The universal microphone switch is turned off.

Voice services

Use your Sonos to control your Sonos system with any voice-enabled Sonos product, play and control content, and more with the voice on device, and more.

- **Sonos Voice Control** (available in some countries) lets you control your Sonos system and play music with your voice. Set up Sonos Voice Control in the Sonos app. Sonos Voice Control is available on select products.
- **Amazon Alexa** (and more) let Sonos play and play with the Sonos skill available. Track Alexa compatibility at sonos.com/alexa. Alexa is a trademark of Amazon.

Note: Set up Sonos Voice Control in the Sonos app. Set up Alexa in the Alexa app. Sonos Voice Control is available on select products.

Trueplay™

Every room is different. Trueplay tuning measures how sound reflects off walls, furnishings, and other surfaces in your room, and then fine-tunes your speaker's audio to sound its best in your specific environment. Trueplay works on iOS devices running iOS 9 or later. During tuning, you'll move around the room, holding your mobile device.

1. Open the Sonos app, and go to **Settings** ⚙.
2. Select **Trueplay Tuning**.
3. Follow the on-screen instructions.

Auto Trueplay

Portable Sonos products like Sonos Roam and Move can tune themselves automatically. Auto Trueplay uses your speaker's microphone to detect the environment and make sonically-exciting adjustments so you get great sound wherever you take your speaker.

1. Select **Settings** ⚙.
2. Choose the product you want to tune.
3. Select **Trueplay**, and turn on **Auto Trueplay**.

Set up stereo pair

Use two Play to create a stereo pair for even better, stereo experience. One speaker serves as the left channel and the partner as the right channel.

Note: The Sonos speakers in a stereo pair must be the same type.

1. Open the Sonos app, and go to **Settings** ⚙. Select the Play you want to be the left channel.
2. Open the Sonos app, and go to **Settings** ⚙.
3. Select **Pair as Stereo Pair** to get started.

Learn more

Product settings

You can customize Sonos products for your surroundings.

1. Go to **Settings** ⚙.
2. Select a product.

Room Name	If you have more speakers in a new room, you can change its name to **Balcony**.
Turn off EQ (not available for Sonos Era 100, Era 300, or portable products)	You can turn off your speaker's EQ when it's connected to your network with an Ethernet cable. Turning off EQ can be helpful if you're using your speaker with a home theater system. For products like Beam and Port, turning off EQ can reduce the volume of dialogue. Turning off EQ can also help if you're using your speaker with a subwoofer. **Learn more**
EQ	**Note:** Don't use when the Bass and Treble controls are unavailable. Learn more about Sonos Cordia Adapter using the Ethernet port. **Learn more** Sonos products offer several customizable audio settings. You can change the sound settings (bass, treble, or loudness) for each your personalized preferences. **Learn more**
Trueplay	Trueplay adapts the sound to your surroundings and content. Portable products can use Sonos microphones and Trueplay. **Learn more**
Volume Limit	You can set a maximum volume for each room. **Learn more**
Status Light	Disables the speaker's connection to Wi-Fi, indicates when the volume is muted, and signals errors. **Learn more** **Note:** If the light is blinking, you can turn it off in **Settings**.
Touch Controls	You can disable the touch control on your speaker. For Sonos app with no phone that is present or within a certain range of your speaker. **Learn more**
Adjustable EQ	In some speaker lets you can set your portable speaker to power off automatically instead of going to sleep. It won't appear in the Sonos app until it's powered back on.
Battery Saver (available products only)	When a product, turntable, stereo, or other audio device is connected to a speaker's line-in port, you can choose how it plays. • **Sonos mode.** Choose a device to the line-in device. • **Audio Out.** Adjust the line-in source level if you find the default volume setting to be quiet or distorted. • **Audio Only.** Add a delay between the line-in source and Sonos to reduce the chance of the audio and video being out of sync when watching a TV or other video source.
Line-In (Sonos products with line-in capability)	• **Autoplay.** Choose to turn if you want a line-in audio to start playing automatically when Sonos detects a signal on the line-in port.

Grouping out of the home

You can group your Play with Sonos speakers in other rooms and zones when you're together, don't connect on one speaker, then press and hold the play/pause button on another to play them together.

You can press and hold the play/pause button on one speaker to add or remove them from a group.

Drying your Play

Play has an IP67 rating, which means water-proof and can be submerged in water up to 3.3 ft (1 meter) for several minutes.

- Make sure the speaker is submerged in such depth that there top or rain water drop in, pool, ocean, beach that the speaker and the water level are in the same plane.
- Position the speaker vertically until it drains. Then place it face down (logo side down) on a dry towel for a few minutes.
- Dab it once more to fully drain moisture out of the acoustic drivers.
- Let the speaker air dry completely before using it again. Only then will it be rated with IP67.

Important: Don't put any audio when the speaker is immersed in water.

Specifications

FEATURE	DESCRIPTION
Audio	
Amplifiers	Three Class-D digital amplifiers
Tweeters	Two angled tweeters create a crisp and accurate high-frequency response and stereo separation
Woofers	One woofer ensures the faithful playback of mid-range and frequencies and deep bass.
Microphones	• Far-field beamforming array • Anti-resonance, noise-rejecting voice control, and fine-tuned EQ using the universal microphone switch on the back of the speaker.
Voice	• Integrated voice control • When the voice service light is off, voice assistants are not listening but other microphone features, like auto Trueplay, are. Sonos can't control or hear your voice unless you initiate night on by the product. **Note:** The universal microphone switch must be turned on.
Auto Trueplay [1]	This software continually optimizes the speaker's sound for its environment and content it's playing. Enable in the Sonos app. **Note:** The universal microphone switch must be turned on.
Adjustable EQ	Use the Sonos app to adjust: • Bass • Treble • Loudness

Power & Connectivity

Charging base	USB-C PD power with 18W (5V/3A) & 45W (15V/3A) Output: 5V 900 mA 15V
Battery (rechargeable)	Sonos Portable supply is not purchased with Play
	Capacity: 3900 mAh **Replacement:** Visit our website for more information. **Battery life:** Battery life will vary depending on usage. Volume to determine the amount of power used by the speaker.
Voice	Connects to Wi-Fi network with any Wi-Fi configuration for 2.4 GHz or 5 GHz broadband capable router
Bluetooth	Bluetooth 5.1 supports audio streaming from any Bluetooth-enabled device
USB-C	Connect an audio source using an auxiliary cable and the Sonos Cordia Adapter. Connect your router with an Ethernet cable and the Sonos Cordia Adapter. Connect your Sonos system to a network.
Charging	The power delivered by the charger must be between 4.5–15 Watts required for charging. Charging with a power less than 4.5 Watts or over the maximum 15 Watts is not supported.
CPU	Quad Core ALC621-VC3
Memory	1 GB DDR4 4 GB flash

Details & Dimensions

Dimensions (H x W x D)	7.83 x 6.93 x 2.83 in (199 x 176 x 72 mm)
Weight	2.99 lb (1.3 kg) (includes battery)
Operating temperature	32° to 104° F (0° to 40° C)
Storage temperature	-13° to 158° F (-25° to 70° C)
Humidity resistant	Play meets IP67 water and dust resistance levels. **Note:** The charging base is for indoor use only.
Colors	Matte black Matte white
What's in the box?	Play, charging base with 6 ft (2 m) USB-C to C cable, and Quickstart guide.

Important safety information

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water. Household cleaners or solvents can damage the finish on your Sonos product.

Sonos products with rubber rings on the bottom, such as Move, Move 2, One, and One SL, don't ship they leave rubber rings on the bottom create a barrier between the product and surface. This may cause damage to some surfaces.

6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
7. Do not place in furniture, clothing racks, or bookcases installed in an enclosed space such as a cabinet.
8. Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Only use attachments/accessories specified by the manufacturer.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. Refer all servicing to Sonos qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
12. Sonos Play meets IP67.

Sonos products with rubber rings on the bottom, such as Move, Move 2, One, and One SL, don't ship they leave rubber rings on the bottom create a barrier between the product and surface. This may cause damage to some surfaces.

13. Do not expose this apparatus to dripping or splashing and do not place objects filled with liquids, such as vases, on the apparatus.
14. To completely disconnect power from the mains, either disconnect the power supply cord from the outlet or from the device. The power supply cord should remain readily accessible to the user.
15. Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
16. Do not push objects of any kind into this product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
17. Clean only with dry cloth.
18. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
19. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
20. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
21. Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
22. Only use attachments/accessories specified by the manufacturer, or sold with the apparatus. Any mounting of the apparatus should follow the manufacturer's instructions, and should use only mounts recommended by the manufacturer.
23. Unplug this apparatus during lightning storms or when unused for long periods of time.
24. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
25. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
26. Objects shall not be placed on the apparatus.
27. Do not expose batteries to excessive heat such as sunshine, fire or the like.
28. Use only in moderate climates.