




USER GUIDE

Indy

Režim párovania

Pairing Mode

- Pairing Mode
- Mode Couplage
- Modo De Vinculación
- Modalità Di Accoppiamento
- Modo Emparejamiento
- Koppelmodus
- Paarmodus
- Pardannelsevstilsstand
- Laiteparin Muodostusta
- Sammenkoblingsmodus
- Parningsläge
- Режим Сопрежения
- 配对模式
- ペアリングモード
- 페어링 모드
- موجه التزاوج
- Režim párovania




Prehrat' ďalšie

Track Forward

Right Side 01
Pravá strana 01

- Track Forward
- Piste Suivante
- Adeklantar
- Branò Successivo
- Faixa Seguinte
- Nächster Titel
- Volgend Nummer
- Skift Til Næste Musiknummer
- Kelkaus Eteenpäin
- Neste Spor
- Nästa Ljudspår
- Переключение На 1 Трек Вперед
- 下一曲目
- 次のトラックを再生する
- 다음 트랙으로
- مسار التالي
- Prehrat' ďalšiu




Aktivovat' hlasového asistenta

Activate Voice Assistant

Right Side 01 or Left Side 02
Pravá strana 01 alebo ľavá strana 02

- Activate Voice Assistant
- Activer l'assistant vocal
- Activar el asistente de voz
- Attivare assistente vocale
- Ativar assistente de voz
- Sprachassistenten aktivieren
- Sternhulp activeren
- Aktivér talestøtte
- Aktivoi ääniohjin
- Aktiver taleassistent
- Aktiviera röstassistent
- Активировать голосовой помощник
- 激活语音助理
- ボイスアシスタントを
- アクティベートする
- 음성 인식 가동화
- تفعيل مساعد صوتي
- Aktivovat hlasového asistenta



L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


ISED Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Automatické zapnutie

Auto Power - On

- Power - On
- On
- Encendido
- Accensione
- Ligar
- Ein
- Aan-
- Tænd
- Virta Päälle
- Strom Av
- Ström Av
- Включить
- 开机
- 電源 - On
- 전원 켜기
- تفعيل التشغيل
- Zápnutie




Spárovat' s novým zariadením

Pair New Device

"Indy"

- Pair New Device
- Coupler Nouvel Appareil
- Vincular Nuevo Dispositivo
- Accoppia Nuovo Dispositivo
- Emparejar Novo Dispositivo
- Mit Neuem Gerät Koppeln
- Nieuw Apparaat Paren
- Pardan Ny Enhet
- Muodosta Uusi Laittepari
- Sammenkoble Ny Enhet
- Para Ny Enhet
- Сопрежение Нового Устройства
- 配对新设备
- 新しいデバイスをペアリング
- 새 기기 짝 맞추기
- موجه تزاوج مع جهاز جديد
- Spárovat' s novým zariadením




Prehrat' predchádzajúce

Track Back

Left Side 02
Ľavá strana 02

- Track Back
- Piste Précédente
- Retroceder
- Branò Precedente
- Faixa Anterior
- Vorangehender Titel
- Vorig Nummer
- Musiknummer Tilbage
- Kelkaus Taaksepäin
- Forrige Spor
- Byta Till Föregående Spår
- Переключение На 1 Трек Назад
- 上一曲目
- 前のトラックを再生する
- 이전 트랙으로
- مسار السابق
- Prehrat' predchádzajúce




Odstránenie spárovaných zariadení

Clear Paired Device

Right Side 01/Left Side 02
*Disconnected Mode
Pravá strana 01/Ľavá strana 02
Režim odpojenia


- Reset Device
- Réinitialiser l'Appareil
- Reiniciar el Dispositivo
- Ripristina Dispositivo
- Reinicie o Dispositivo
- Rückstelleneinrichtung
- Reset het Apparaat
- Nustiti Enhed
- Nollaa Laite
- Nustiti Enhed
- Återställ Enheten
- Сброс устройства
- 重置设备
- デバイスをリセット
- 기기 재설정
- راه حل باطله
- Odstránenie spárovaných zariadení



Automatické vypnutie

Auto Power - Off

- Power - Off
- Off
- Apagado
- Spegnimento
- Desligar
- Aus
- Uitzetting
- Sluk For Strøm
- Pois
- På
- På
- выключить Питание
- 关机
- 電源 - Off
- 끄기
- تفعيل إيقاف التشغيل
- Vypnutie




Zapnutie

Power - On

Right Side 01
Pravá strana 01

- Power - On
- On/off
- Encendido
- Accensione
- Ligar
- Ein
- Aan-
- Tænd
- Virta Päälle
- Strom Av
- Ström Av
- Включить
- 开机
- 電源 - On
- 전원 켜기
- تفعيل التشغيل
- Zápnutie




Zvýšit' hlasitost'

Volume Up

Right Side 01
Pravá strana 01


- Volume Up
- Volume +
- Bajar Volumen
- Aumento Volume
- Aumentar O Volume
- Lautstärke Erhöhen
- Volume Omhoog
- Skrü Op For Lydstyrken
- Äänenvoimakkuuden Lisäys
- Volym Opp
- Öka Volymen
- Увеличение Громкости
- 音量増大
- 音량을上げる
- 볼륨 높이기
- رفع مستوى الصوت
- Zvýšit' hlasitost'



Nabíjanie púzdra

Charge Case

- Charge Case
- Rechargez L'étui
- Estuche De Carga
- Carica La Custodia
- Estojo De Carregamento
- Hülle Aufladen
- Opladetui
- Opladeretui
- Lataa Kotelo
- Ladingseske
- Laddningsfodral
- Чехол-аккумулятор
- 充電座
- 充電ケース
- 케이스를 충전하세요
- تفعيل شحن
- Nabíjanie púzdra




Vypnutie

Power - Off

Right Side 01
Pravá strana 01

- Power - Off
- Off
- Apagado
- Spegnimento
- Desligar
- Aus
- Uitzetting
- Sluk For Strøm
- Pois
- På
- På
- выключить Питание
- 关机
- 電源 - Off
- 끄기
- تفعيل إيقاف التشغيل
- Vypnutie




Nížit' hlasitost'

Volume Down

Left Side 02
Ľavá strana 01


- Volume Down
- Volume -
- Bajar Volumen
- Riduzione Volume
- Diminuir O Volume
- Lautstärke Senken
- Volume Omaag
- Skrü Ned For Lydstyrken
- Äänenvoimakkuuden Vähennys
- Volym Ned
- Sänka Volymen
- Уменьшение Громкости
- 音量减小
- 音량을lower
- 볼륨 낮추기
- خفض مستوى الصوت
- Nížit' hlasitost'



Nabíjanie slúchadiel

Charge Earbuds

- Charge Earbuds
- Rechargez Les Écouteurs
- Audifonos De Carga
- Carica Gli Auricolari
- Carregar Auriculares
- Kopfhörer Aufladen
- Opladen Oordoppen
- Oplad Høretelefoner
- Lataa Nappikuulokkeet
- Lade Örepluggar
- Ladda Öronsnäckor
- Наушники С Аккумулятором
- 为耳机充电
- イヤホン充電
- 이어버드를 충전하세요
- تفعيل شحن سماعات
- Nabíjanie slúchadiel



Prehrávanie/Pauza

Play/Pause

Right Side 01
Pravá strana 01

- Play/pause
- Lecture/pause
- Reproducir/pausar
- Riproduci/pausa
- Reproducir/colocar Em Pausa
- Wiedergabe/pause
- Afspelen/pauzeren
- Afspil/pause
- Toisto/tauko
- Spill/pause
- Spela Upp/pausa
- Воспроизведение/пауза
- 播放/暫停
- 再生 /一時停止
- 재산/일시 정지
- تفعيل تشغيل/توقف
- Prehrávanie/Pauza




Odpovedat/Ukončit'

Answer/End

Right Side 01
Pravá strana 01

- Answer/end
- Répondre/fin
- Responder/colgar
- Risposta/line
- Atender/desligar
- Annehmen/beenden
- Beantwoorden/beëindigen
- Besvar/afslut
- Vastaus/lopetus
- Svar/avslutt
- Svara/lögg På
- Отвeтить/закончить
- 接听/結束
- 応答 / 終了
- 전화 받기/끝기
- تفعيل الرد
- Odpovedat/Ukončit'



FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Questions Visit: www.skullcandy.com
Si vous avez des questions, allez sur : www.skullcandy.com
Si tienes dudas, visita: www.skullcandy.com
Domande Visitate il sito: www.skullcandy.com
Fazer perguntas: www.skullcandy.com
Fragen Besuch: www.skullcandy.com
Voor vragen bezook: www.skullcandy.com
For sporssmål se: www.skullcandy.com
Vastauksia löyty: www.skullcandy.com
For spørsmål, besøk: www.skullcandy.com
Если у вас возникнут вопросы, посетите: www.skullcandy.com
如有问题请访问: www.skullcandy.com
質問がある場合はこちらをご覧ください: www.skullcandy.com
문의 사항: www.skullcandy.com
www.skullcandy.com ھەمچەن ئۆزگەرتىش ۋە تەكشۈرۈش ئۈچۈن بۇ ئورۇننى كۆرۈڭىز.

Americas
Skullcandy, Inc.
6301 N Landmark Dr.
Park City, UT 84098 U.S.A.
Skullcandy.com

Europe
Skullcandy Europe BV
Postbus 425
6500AK Veldhoven Nederland
Skullcandy.eu

México
Skullcandy Mexico S de RL de CV
Aristoteles 218
Polanco IV Sección, Miguel Hidalgo
11520, México City, México
Skullcandy.mx

Canada
Skullcandy Canada ULC
329 Railway St, Unit 205
Vancouver, BC, V6A 1A4 Canada
Skullcandy.ca

Japan/日本
Skullcandy Japan合同会社
〒150-0001 東京都渋谷区神宮前
5-17-11 パークサイドオーガーキ2階
Skullcandy Japanカスタマーサービス
商品についてのお問い合わせはこちら
Skullcandy.jp

EN Contains Li-ion battery. Battery must be recycled or disposed of properly.
FR Contient une batterie Li-ion.La batterie doit être recyclée ou jeté s correctement.
ES Contiene una batería Li-ion. La batería debe ser reciclada o desechada adecuadamente.
Hardware Version: V1.3
Software Version: V6.0
CZ Obsahuje Li-Ion baterii. Baterie musí být recyklována nebo řádně zlikvidována.
R-C-Sku-S2SSW



SK: Vyrobené v Číně

EN Made in China.
FR Fabriqué en Chine.
ES Hecho en China.
ZH 中国制造

MODEL: S2SSW
FCC ID: Y22-S2SSW
IC: 10488A-S2SSW

