













	<p>Power - On *On Mode (Main Button)</p>  <p>00:01</p>	<p>Power - Off *On Mode (Main Button)</p>  <p>00:03</p>	<p>Pairing Mode *On Mode (Main Button)</p>  <p>00:03</p>
<p>Pairing Mode *On Mode (Main Button)</p>  <p>00:03</p>	<p>Pair New Device Voice Prompt - "Ready to Pair" Available Device - "HESH 360"</p>  <p>LED Pulses</p>	<p>Play / Pause - Answer Call (Joystick) *Press Right</p>  <p>1x</p>	<p>Next Track (Joystick) *Press Right</p>  <p>1x</p>	<p>Previous Track (Joystick) *Press Left</p>  <p>1x</p>
<p>Volume Up (Joystick) *Press Up</p>  <p>1x</p>	<p>Volume Down (Joystick) *Press Down</p>  <p>1x</p>	<p>Reject / End Call (Joystick) *Call Mode</p>  <p>00:01</p>	<p>Plug in to Charge</p> 	<p>Activate Assistant (Joystick)</p>  <p>2x</p>
<p>Reset / Clear Paired Device List (Joystick) *On Mode *Bluetooth Disconnected</p>  <p>00:06</p>				